

Product Specifications & User Manual

5-Unit Charge Station for LP5 (PSLP5-LP5PC-KIT)



Power Supply	PSU AC INPUT 100-240V 1.8A, 50-60Hz
Compatibility	Linea Pro 5 (all models) with Protective Case component: <ul style="list-style-type: none"> • CS-RMS-LP52D-STR-G/BK • CS-R-LP52D-STR-G/BK • CS-RMS-LP51D-STR-G/BK • CS-R-LP51D-STR-G/BK <p>iPhone 5/5s, iPhone SE, iPod Touch 5th, 6th & 7th Gen</p>
LEDs	5 LEDs for battery charging status
Operating Environment	Operating temperature: 0°C to +40°C Operating humidity: 35 to 85% RH Storage temperature: -5°C to +40°C Storage humidity: 10 to 90% RH
Dimensions	3.9 in x 10.2 in x 1.4 in
Weight	12.49 oz
Certifications	CE, FCC, RoHS

www.stimare.net

www.lineapro.store

info@stimare.net

info@lineapro.store

USA +1-720-257-7070

UK +44-208-0998071

Ireland +353-1-6854600

We are the experts in:

BARCODE SCANNING

MOBILE PRINTING

POINT-OF-SALE (POS)

Package Contents:

- 1 x Linea Pro 5 Unit Charger (model: PSLP5-LP5PC-KIT)
- 1 x AC adaptor box with integrated cable and plug
- 1 x Mains Power Cable and Plug

Important Safety Instructions

This document contains important safety and operating instructions.

Please read these instructions carefully and save them for future reference. Before using the battery charger, read any the instructions and cautionary markings on the charger and the Linea Pro Device using the battery.

1. To reduce risk of damage to the power supply, electric plugs and cords, pull the plug rather than the cord when disconnecting from the AC outlet or the charger.
2. An extension cord should not be used unless absolutely necessary. Use of an improper extension cord could result in risk of fire and electric shock. If an extension cord must be used, make sure that the cord size is 18 AWG for lengths of up to 6.5 feet (2.0 m), and 16 AWG for lengths up to 9.8 feet (3.0 m).
3. To reduce risk of fire, electric shock, or injury, do not operate the charger if it has been broken or damaged in any way.
4. Do not disassemble the charger. It is not repairable and replacement parts are not available. Disassembly of the charger may result in risk of electric shock or fire.
5. To reduce risk of electric shock, unplug the charger power supply from the AC outlet before attempting any cleaning.

Operational Safety Guidelines

- This equipment is not suitable for outdoor use. Use only in dry locations and conditions.
- Maximum ambient temperature around the charger must not exceed 40 °C (104 °F).

Setup and Usage instructions:

Step 1.

Please connect the AC adaptor plug to the far end of the 5-unit charger piece, ensure the power supply box is assembled and then proceed to plug the mains plug to your electrical outlet socket.




Once power is received by the unit, the LED status lights should be illuminated steady green, indicating that each individual slot is ready to charge a device.



Step 2.

To charge your device(s) please place each Linea Pro 5 device with protective case firmly inside each free charging slot. When the pogo pin connection is made, the LED status will change to solid red. When each device is fully charged the LED status indicator will change to a Blinking Green.



<u>LED Status Indicator chart:</u>	
Steady Green:	 Charge Port is ready to receive a device for charging
Steady Red:	 Charging is in Progress
Blinking Green:	*  * Charging is complete and device battery is fully charged

Troubleshooting steps:

If a charging slot is not charging your device(s) successfully, please firstly unplug the unit for the mains power and proceed to ensure that there is no dirt or debris obstructing the pogo pins inside the affected charging slot.

If only one of your Linea Pro 5 Devices is not charging properly with the 5-unit charger, please ensure that there is no dirt or debris obstructing the 2 gold plated circular charging contacts, located on the bottom of your Linea Pro 5 device. If contact cleaning is necessary, please firstly remove the device from the protective case and proceed to clean each individual charging contact plate with a cotton bud dipped in a small amount of Isopropyl Alcohol (99%+) before retrying.

Warranty

Stimare provides a one-year limited warranty. This warranty does not cover any product which has been subject to improper use, neglect or unauthorized repair or installation. This warranty does not cover consumable parts. (Cables & batteries are consumables.) Returns for service can be requested on: stimare.returnsportal.net

